




AquaSkim


20, 40

DE Gebrauchsanleitung
EN Operating instructions
FR Notice d'emploi
NL Gebruiksaanwijzing
ES Instrucciones de uso
PT Instruções de uso
IT Istruzioni d'uso
DA Brugsanvisning
NO Bruksanvisning
SV Bruksanvisning
FI Käyttöohje


HU Használati útmutató
PL Instrukcja użytkowania
CS Návod k použití
SK Návod na použitie
SL Navodila za uporabo
HR Uputa o upotrebi
RO Instrucţiuni de folosinţă
BG Упътване за употреба
UK Посібник з експлуатації
RU Руководство по эксплуатации
ZH 使用说明书



AquaSkim 20





AquaSkim 40



ASM0001




AquaSkim		20	40
m ²		20 m ²	40 m ²
2000-6000 l/h		6000-16000 l/h	
AquaMax Eco Premium	4000	3, 4	—
	6000	2, 3, 4	—
	8000	1, 2, 3	3, 4
	10000	1, 2	3, 4
	12000	—	2, 3, 4
	16000	—	2, 3, 4
Twin	20000	—	min. 50 %
	30000	—	min. 50 %











ASM0006



	[mm]		
AquaSkim	A	B	C
20	min. 850 max. 1070	min. 600 max. 850	min. 370 max. 600
40	min. 880 max. 1100	min. 630 max. 880	min. 380 max. 630
	 ID 35262		








ASM0002



ASM0003




AquaSkim	x	y
20	60 mm	± 50 mm
40	75 mm	± 60 mm



ASM0004



Pos.	AquaSkim	
	20	40
1	21110	33284
2	21109	33285
3	21111	35263
4	35264	35264
5	26737	26737
6	35262	35262
7	27027	27027
8	35304	35304



ASM0005

OASE GmbH

Tecklenburger Straße 161
48477 Hörstel | Germany

☎ +49 (0) 5454 80-0

✉ info@oase.com